

# ELECTRICAL ACCESSORIES // PARTS & ACCESSORIES

Code	
<b>MM-00127</b>	Wall mounting adapter plate (Reducer 63/80)
<b>MM-00126</b>	Wall mounting plate (Reducer 80/100)
<b>MM-00295</b>	Wall mounting plate (Reducer 120)
<b>MM-00334</b>	Bearing support plate for 5HP PRO-GH (reducer 120)
<b>MW-00057</b>	Splash proof covers light duty, PRO-LJ, LH, LHA, GJ (fully assembled)
<b>MW-00020</b>	Splash proof covers, PRO-T/TB (fully assembled)
<b>MW-00021</b>	Splash proof covers, PRO-H, J, HHD, GH, GHC (fully assembled)
<b>MW-00024</b>	Chain spreader 1" - 1"
<b>MW-00025</b>	Chain spreader 1" - 1-1/4"
<b>MW-00026</b>	Chain spreader 1-1/4" - 1-1/4"
<b>MW-00059</b>	Chain spreader 1-3/8" - 1-1/4"
<b>MP-00075</b>	Heavy duty front idler (trolley end bracket) #410
<b>MP-00076</b>	Heavy duty front idler (trolley end bracket (#41))
<b>MP-00077</b>	Heavy duty front idler #41 c/w pillow blocks

## LIMIT SWITCHES

Code	
<b>MK-00004</b>	Travel limit switch (Micanan)
<b>MK-00605</b>	Double limit switch (Micanan)
<b>MK-00005</b>	Cut-out limit switch (Micanan)
<b>MK-00024</b>	Single limit switch AT
<b>MK-00025</b>	Double limit switch DAT
<b>MK-00063</b>	Honeywell limit switch
<b>MK-00099</b>	Utility limit switch (telemecanique) c/w roller
<b>MV-00214</b>	Tele 8" wand (for utility switch)

## TRANSFORMERS

Code	
<b>MK-00030</b>	115V - 24V - 40VA
<b>MK-00142</b>	115V - 24V - 50VA
<b>MK-00031</b>	230V - 24V - 40VA
<b>MK-00228</b>	230V - 24V - 50VA
<b>MK-00032</b>	460V - 24V - 40VA
<b>MK-00248</b>	460V - 24V - 50VA
<b>MK-00033</b>	575V - 24V - 40VA
<b>MK-00055</b>	575V - 24V - 50VA
<b>MK-00056</b>	230V - 115V - 50VA
<b>MK-00057</b>	460V - 115V - 50VA
<b>MK-00071</b>	575V - 115V - 50VA
<b>MK-00225</b>	110V - 24V - 100VA
<b>MK-00141</b>	220V - 24V - 100VA
<b>MK-00222</b>	460V - 24V - 100VA
<b>MK-00137</b>	600V - 24V - 100VA
<b>MK-00175</b>	220V - 110V - 100VA
<b>MK-00223</b>	460V - 110V - 100VA
<b>MK-00100</b>	575V - 110V - 100VA

## CONTROL RELAYS

Code	
<b>MK-00012</b>	24VAC coil DPDT (flange mount)
<b>MK-00013</b>	120VAC coil DPDT (flange mount)

# ELECTRICAL ACCESSORIES // PARTS & ACCESSORIES

Code	
<b>MK-00014</b>	220VAC coil DPDT (flange mount)
<b>MK-00428</b>	24VAC coil 3-pole TPDT (PRO-LTB, LJ, LH, LHAB) (flange mount)
<b>MK-00429</b>	24VAC coil 4-pole QPDT (PRO-LJ, LH, LHAB) (flange mount)
<b>MK-00140</b>	24VDC coil DPDT (flange mount)
<b>MK-00346</b>	12VAC 8-pin plug-in relay
<b>MK-00522</b>	24VAC 8-pin plug-in relay
<b>MK-00562</b>	120VAC 8-pin plug-in relay
<b>MK-00062</b>	8-pin relay/timer base

## REVERSING CONTACTORS

Code	
<b>MK-00493</b>	Telemecanique 24V coil
<b>MK-00508</b>	Telemecanique 120V coil
<b>MK-00066</b>	Allen Bradley 24V coil
<b>MK-00067</b>	Allen Bradley 120V coil
<b>MK-00068</b>	Struthers Dunn 24V coil
<b>MK-00108</b>	Telemecanique circuit board contactor (24V)
<b>MK-00523</b>	ABB size 1 reversing contactor 24V with interlock
<b>MK-00404</b>	ABB size 1 reversing contactor 120V with interlock

## SOLENOIDS

Code	
<b>MK-00026</b>	120V
<b>MK-00027</b>	240V
<b>MK-00503</b>	380V
<b>MK-00028</b>	460V
<b>MK-00029</b>	575V

## OVERLOAD RESETS 1 PHASE

Code		
<b>MK-00034</b>	1-Phase	5 Amps
<b>MK-00035</b>	1-Phase	6 Amps
<b>MK-00036</b>	1-Phase	7 Amps
<b>MK-00037</b>	1-Phase	8 Amps
<b>MK-00038</b>	1-Phase	9 Amps
<b>MK-00039</b>	1-Phase	10 Amps
<b>MK-00041</b>	1-Phase	12 Amps
<b>MK-00042</b>	1-Phase	13 Amps
<b>MK-00043</b>	1-Phase	15 Amps
<b>MK-00044</b>	1-Phase	17 Amps
<b>MK-00045</b>	1-Phase	18 Amps
<b>MK-00046</b>	1-Phase	20 Amps
<b>MK-00047</b>	1-Phase	25 Amps

## OVERLOAD RESETS 3 PHASE

Code		
<b>MK-00139</b>	3-Phase	0.8- 1.2 Amps
<b>MK-00048</b>	3-Phase	1.2- 1.8 Amps
<b>MK-00049</b>	3-Phase	1.8- 2.6 Amps
<b>MK-00050</b>	3-Phase	2.6- 3.7 Amps
<b>MK-00051</b>	3-Phase	3.7- 5.5 Amps
<b>MK-00052</b>	3-Phase	5.5- 8 Amps

# ELECTRICAL ACCESSORIES // PARTS & ACCESSORIES

Code	
<b>MK-00053</b>	3-Phase 8.0- 11.5 Amps
<b>MK-00054</b>	3-Phase 12- 16 Amps
<b>MK-00019</b>	Overload base for above

## ELECTRICAL COMPONENTS

Code	
<b>MK-00009</b>	9-Pole terminal strip (Control)
<b>MK-00010</b>	3-Pole terminal strip (Power)
<b>MK-00696</b>	4-Pole terminal strip
<b>MK-00160</b>	12-Pole terminal strip
<b>MK-00011</b>	Radio control terminal strip
<b>MK-00015</b>	2 Amp glass fuse
<b>MK-00016</b>	Fuse holder
<b>MK-00017</b>	Ground lug
<b>MK-00430</b>	Capacitor 240V 70 mF (For limited duty 110V operators)
<b>MK-00398</b>	Capacitor 370V 20 mF (For limited duty 220V operators)
<b>MK-00006</b>	BX Conduit 1/2" ID x 5/8" OD
<b>MK-00511</b>	Limited duty operator resistor assembly

## REPLACEMENT COMPONENTS FOR SMART 10.0 LOGIC BOARD CONTROLS

Code	
<b>MK-00641</b>	Micanan full feature logic board with 5 relays (for 1/3, 1/2, 3/4HP - 110/220V 1-Ø, 230V 3-Ø)
<b>MK-00736</b>	Micanan non-monitored full feature logic board with 5 relays (for 1/3, 1/2, 3/4HP - 110/220V 1-Ø, 230V 3-Ø)
<b>MK-00701</b>	Micanan full feature logic board with heavy duty relays (for 1HP - 110/220V 1-Ø, 230V 3-Ø)
<b>MK-00829</b>	Micanan non-monitored full feature logic board with heavy duty relays (for 1HP - 110/220V 1-Ø, 230V 3-Ø)
<b>MK-00642</b>	Micanan full feature logic board with contactor interface (for all HP - 460/575V, all voltages 1.5, 2, 3, 5HP)
<b>MK-00737</b>	Micanan non-monitored full feature logic board with contactor interface (for all HP - 460/575V, all voltages 1.5, 2, 3, 5HP)
<b>MK-00488</b>	Micanan limited duty logic board 5.0
<b>MK-00897</b>	Micanan non-monitored limited duty logic board 5.0
<b>MK-00108</b>	Telemecanique contactor (24V) for logic board w/ contactor interface
<b>MK-00643</b>	Micanan apartment auxiliary board with harness
<b>MK-00694</b>	10K OHM resistor
<b>MK-00644</b>	Micanan 6-wire limit switch circuit board plug-in harness
<b>MK-00645</b>	Micanan 3-wire external radio control plug-in harness
<b>MK-00646</b>	Micanan coax cable
<b>MK-00719</b>	Micanan antenna for on-board receiver
<b>MK-00666</b>	RF junction connector for antenna
<b>MK-00679</b>	Plastic shoulder for antenna connector
<b>MK-00680</b>	Plastic nut for antenna connector
<b>MK-00703</b>	Harness 1-phase 5-relay board
<b>MK-00704</b>	Harness 1-phase contactor board
<b>MK-00705</b>	Harness 3-phase 5-relay board
<b>MK-00706</b>	Harness 3-phase contactor board
<b>MK-00707</b>	Varistor harness 110V with black wires
<b>MK-00708</b>	Varistor harness 230V with blue wires
<b>MK-00711</b>	Varistor harness 380V with yellow wires
<b>MK-00709</b>	Varistor harness 460V with red wires
<b>MK-00710</b>	Varistor harness 575V with brown wires

# ELECTRICAL ACCESSORIES // PARTS & ACCESSORIES

Code	
<b>MM-00360</b>	Circuit board support U-bracket
<b>MM-00366</b>	Circuit board N-4 support U-bracket
<b>MG-00127</b>	Plastic spacer for boards (Short length 0.382")
<b>MG-00054</b>	Plastic spacer for boards (Medium length 0.768")
<b>MG-00082</b>	Plastic spacer for boards (Long length 1.190")

## REPLACEMENT COMPONENTS FOR INTERFACE MODULE CONTROLS

Code	
<b>MK-00651</b>	Micanan interface module
<b>MK-00694</b>	10K OHM resistor
<b>MK-00717</b>	1-phase harness for interface module
<b>MK-00716</b>	3-phase harness for interface module
<b>MK-00715</b>	Standard light duty harness for interface module (LH)
<b>MK-00714</b>	Standard light duty harness for interface module (RH)
<b>MM-00367</b>	N-4 interface module support bracket

# ELECTRICAL ACCESSORIES // PARTS & ACCESSORIES

## ELECTRIC MOTORS

	Code						
LT, LJ, LH, LHA	<b>MB-01010</b>	Limited Duty	1/2HP	110V	1PH	60Hz	
	<b>MB-01007</b>	Limited Duty	1/2HP	220V	1PH	50/60Hz	
	<b>MB-01011</b>	Limited Duty	1/2HP	380V	3PH	50Hz	
GJ	<b>MB-01008</b>	Limited Duty GJ	1/2HP	110V	1PH	60Hz	
	<b>MB-01009</b>	Limited Duty GJ	1/2HP	575V	3PH	60Hz	
APT/E	<b>MB-01301</b>	1/2HP	110V	1PH (Instant Reverse, Resilient base)		FR56	
	<b>MB-01302</b>	1/2HP	220V	1PH (Instant Reverse, Resilient base)		FR56	
APTC	<b>MB-01006</b>	1/2HP	110V	1PH (Instant Reverse)		FR56C	
T, TB, APT, APTC, J, EJ, H, EHJ, HDD, SD	<b>MB-00001</b>	1/3HP	110/220V	1PH	Base Mount	O.D.P.	FR56
	<b>MB-01001</b>	1/2HP	110/220V	1PH	Base Mount	O.D.P.	FR56
	<b>MB-02001</b>	3/4HP	110/220V	1PH	Base Mount	O.D.P.	FR56
	<b>MB-03001</b>	1 HP	110/220V	1PH	Base Mount	O.D.P.	FR56
	<b>MB-01102</b>	1/2HP	230/460V	3PH	Base Mount	O.D.P.	FR56
	<b>MB-01202</b>	1/2HP	575V	3PH	Base Mount	O.D.P.	FR56
	<b>MB-02102</b>	3/4HP	230/460V	3PH	Base Mount	O.D.P.	FR56
	<b>MB-02202</b>	3/4HP	575V	3PH	Base Mount	O.D.P.	FR56
	<b>MB-03102</b>	1 HP	230/460V	3PH	Base Mount	O.D.P.	FR56
	<b>MB-03202</b>	1 HP	575V	3PH	Base Mount	O.D.P.	FR56
	<b>MB-00002</b>	1/3HP	110/220V	1PH	Base Mount	TEFC	FR56
	<b>MB-01002</b>	1/2HP	110/220V	1PH	Base Mount	TEFC	FR56
	<b>MB-02002</b>	3/4HP	110/220V	1PH	Base Mount	TEFC	FR56
TW, TBW, JW, HW, HDDW, SDW	<b>MB-03002</b>	1 HP	110/220V	1PH	Base Mount	TEFC	FR56
	<b>MB-05505</b>	1/2HP	230/460V	3PH	Base Mount	TEFC	FR56
	<b>MB-05508</b>	1/2HP	575V	3PH	Base Mount	TEFC	FR56
	<b>MB-05506</b>	3/4HP	230/460V	3PH	Base Mount	TEFC	FR56
	<b>MB-05509</b>	3/4HP	575V	3PH	Base Mount	TEFC	FR56
	<b>MB-05507</b>	1 HP	230/460V	3PH	Base Mount	TEFC	FR56
	<b>MB-05510</b>	1 HP	575V	3PH	Base Mount	TEFC	FR56
	<b>MB-01003</b>	1/2HP	110/220V	1PH	C-Flange	TEFC	56C
	<b>MB-02004</b>	3/4HP	110/220V	1PH	C-Flange	TEFC	56C
	<b>MB-03004</b>	1 HP	110/220V	1PH	C-Flange	TEFC	56C
GT, GH, GHC, GSD	<b>MB-04001</b>	1.5HP	110/220V	1PH	C-Flange	TEFC	56C
	<b>MB-05001</b>	2 HP	110/220V	1PH	C-Flange	TEFC	56C
	<b>MB-01104</b>	1/2HP	230/460V	3PH	C-Flange	TEFC	56C
	<b>MB-01204</b>	1/2HP	575V	3PH	C-Flange	TEFC	56C
	<b>MB-02104</b>	3/4HP	230/460V	3PH	C-Flange	TEFC	56C
	<b>MB-02204</b>	3/4HP	575V	3PH	C-Flange	TEFC	56C
	<b>MB-03104</b>	1 HP	230/460V	3PH	C-Flange	TEFC	56C
	<b>MB-03204</b>	1 HP	575V	3PH	C-Flange	TEFC	56C
	<b>MB-04204</b>	1.5HP	230/460V	3PH	C-Flange	TEFC	56C
	<b>MB-04504</b>	1.5HP	575V	3PH	C-Flange	TEFC	56C
	<b>MB-05204</b>	2 HP	230/460V	3PH	C-Flange	TEFC	56C
	<b>MB-15104</b>	2 HP	230/460V	3PH	C-Flange	TEFC	145TC
	<b>MB-05504</b>	2 HP	575V	3PH	C-Flange	TEFC	56C
	<b>MB-15204</b>	2 HP	575V	3PH	C-Flange	TEFC	145TC
	<b>MB-16104</b>	3 HP	230/460V	3PH	C-Flange	TEFC	182TC
	<b>MB-16204</b>	3 HP	575V	3PH	C-Flange	TEFC	182TC
	<b>MB-16107</b>	3 HP	230/460V	3PH	Brake motor	C-Flange	TEFC